

FIG. 1


Speaker 16
Page indicator 30
Touch panel 14
Memory card 17
20
Processor 21
Memory 22
Operating buttons 23

FIG. 2


301
Touching the touch panel 14
302
Sending out a touch single to the electronic control unit 20
303
Determining if a page indication area 141 was touched
No
305
Executing a corresponding command
Yes
304
The corresponding page indicator 30 is activated

FIG. 3



FIG. 4



FIG. 5

Position 1	Learning card 1
Position 2	Learning card 2
Position 3	Learning card 3
• • •	• • •
Position N	Learning card N

FIG. 6

	Learning card 1	Learning card 2	• • •	Learning card N
PositionA	Command1-A	Command2-A	• • •	CommandN-A
PositionB	Command1-B	Command2-B	• • •	CommandN-B
• • •	• • •	• • •	• • •	• • •
PositionX	Command1-X	Command2-X	• • •	CommandN-X

FIG. 7



FIG. 8



FIG. 9



FIG. 10